



- NOTES:
1. FLOWABLE MORTAR FILL UTILITY LINE SUPPORT TO BE USED WHEN NEW UTILITY EXCAVATION IS CROSSING UNDER AN EXISTING UTILITY LINE (SEWER LINES, WATER LINES, GAS LINES, ETC.) AS DIRECTED BY THE ENGINEER.
  2. ALLOW FLOWABLE MORTAR FILL TO CURE A MINIMUM OF 24 HRS. BEFORE COMPLETING BACKFILL.
  3. UNCOMPACTED BACKFILL SHALL BE TRIMMED AWAY FROM SLOPES BEFORE POURING FLOWABLE MORTAR.
  4. SIDE SLOPES OF FLOWABLE MORTAR FILL TO BE 1:1 SLOPE OR GREATER. SEE SECTION A-A.

			FLOWABLE MORTAR FILL UTILITY LINE SUPPORT	FIGURE: 3010.6
REV.	DATE	BY		DATE: 01-01-98