



ENCASE THE BEND(S) IN P.C. CONCRETE TO PROVIDE SUPPORT. DO NOT PLACE CONCRETE ABOVE THE UPPER JOINT AS SHOWN.

- ① THE DROP PIPE FITTINGS SHALL BE DUCTILE IRON PIPE OF THE SAME SIZE AS THE SEWER BEING CONSTRUCTED.
- ② WRAP JOINT TO KEEP OUT FLOWABLE MORTAR.
- ③ CONSTRUCT DROP WITH MECHANICAL JOINT FITTINGS.

I	01/25/99	
REV.	DATE	BY
DATE:	01-01-98	

DROP CONNECTION (SANITARY SEWER)
CONCRETE ENCASED