

## LEGEND

- Traffic Sign
- O 42" Channelizer or Vertical Panel



Work Area

→ Direction of Traffic

| SPEED<br>LIMIT<br>(mph) | A     | В    | Т    | c <sup>②</sup> |
|-------------------------|-------|------|------|----------------|
| 40 or less              | 500′  | 250′ | 100′ | 40′            |
| 45 - 50                 | 700′  | 350′ | 200′ | 80′ ①          |
| 55 - 60                 | 1500′ | 500′ | 200′ | 100′ ①         |
| 65 - 70                 | 1500' | 500' | 230' | 100′ ①         |

When a shoulder drop-off of 6" or less exists, install a SHOULDER DROP-OFF sign, as shown.

When a shoulder drop-off greater than 6" exists, install a NO SHOULDER sign, as shown.

Where the length of a shoulder drop-off exceeds 1000 feet, construct a temporary fillet meeting the requirements of Article 1107.09 of the Standard Specifications.

Drop-offs greater than a nominal 10" will not be allowed during non-working hours.

- ① Spacing = 40' when shoulder drop-offs are present.
- ② For work areas less than 200' long, use channelizers spaced at 20' centers or use a vehicle with an amber revolving light or amber strobe light.

Contract Item:

Traffic Control

