Use of LEAP Analysis with OpenBridge Designer

OpenBridge Designer can be used for analysis without a model created through OpenBridge Modeler. The Standalone File Groups option must be used. If the BIM Workflow option is used, then the model of the bridge is needed and sent to the analysis programs.

The following steps should be followed:

- 1. Launch OpenBridge Designer.
- 2. Create an obdx file.
 - Select New File.
 - Navigate to location to create new file.
 - Enter a name that matches the project directory number or a name that logically indicates the work you are doing.

🌃 Save As						×
\leftarrow \rightarrow \checkmark \uparrow \square \Rightarrow This PC	> Windows (C:) > TEMP > OBD) Testing	~	ට 🔎 Sea	rch OBD Testing	
Organize 🔻 New folder						?
AutoHotkey_1. ^ Nat BentleyDownlc Documents an ePower Intel Oracle PerfLogs Program Files Program Siles ProgramData pw_work Python27 Recovery System Volume	me	Date modified No items match	Type a your search.	Size		
File <u>n</u> ame: 9999999997	obdx					~
Save as type: OBDX files(* A Hide Folders	.obdx)			<u>S</u> av	e Cancel	~

- Click Save button.
- 3. Create Standalone Group.
 - Select Standalone workflow option.
 - Click the Add Group button (folder with green plus).

🖉 0603003092.obd - OpenBridge Designer	
File	
Standalone File Groups	
BIM Workflow Standalone	
Add a group to begin	

• Enter the project name for name of the group.



- Click OK button.
- 4. Click on the Analysis icon.

OpenBridge Designe	r CONNECT Edition
Modeling Analysis	Drawings Interop.
Anal	ysis
LEAP Bridge Steel	File Not Created Run application to begin.
LEAP Bridge Steel	File Not Created Run application to begin. File Not Created Run application to begin.

- 5. Launch LEAP Bridge Concrete (or other application) from the shortcut for applications listed in the lower portion.
- 6. Proceed with entry of model and typical analysis steps.
- 7. Click on File > Save or File > Save As to save the model.
- 8. Enter the file name.
- 9. Click OK button.
- 10. The analysis file will be added to the list in the obdx file.
- 11. Reopen the existing analysis files by selecting in the group list in the obdx file and launching the appropriate analysis application.

As a workflow example, to create a Substructure only file:

- Complete steps 1-5.
- Access the Substructure tab and click on Substructure button to launch Substructure (RC Pier) module.

EAP Bridge Concrete CONNECT Edition - Untitled *
File Edit View Tools 2D Viewer Options Help
1 New Open Save Save As Print A B C Preferences Graphics Reports Help Bentley Site
1
🔛 Project 🗻 Geometry 🖙 SuperStructure 🎹 SubStructure 📰 Reports 🖊 Drawings
Substructure
Abut/Pier List:
Design Spec: AASHTO Edit Bearings/Steps

- o Build the model.
- Click on File > Save or File > Save As and save the model.
- Enter the file name.
- Click OK button.
- When you exit the substructure module, the analysis file will be added to the list in the obdx file.

🌆 99999999997.obdx - OpenBridge Designer	
File	
Standalone File Groups	
BIM Workflow Standalone	
▲ Standalone Group : Testing OBD Analysis	
🐴 Pier Cap.lbcx	
	ŀ

 Reopen the saved analysis file by selecting it in the list and Launch LEAP Bridge Concrete. It will open the Substructure module.



Notes:

- The obdx file is required for managing the analytical files. The location of the file can be on local or network drive or on ProjectWise server.
- The files are saved within the obdx database only and are not available outside the OpenBridge Designer interface.
- If only doing analysis, when you close an analysis module you may see a dialog box indicating to update the model. Make sure to click the No button and exit.

LEAP Bridge Concrete CE V20	×
? Would you like to update the LEAP Bridge C	oncrete model?
Yes No	Cancel

- Existing LEAP Bridge Concrete files created with a previous version can be opened to start a new file.
 - Highlight the Standalone group not a listed file.

 # 99999997.abdx OpenBridge Designer
 Ein

File				
	OpenBri	dge Design	er CONNECT E	dition
Standalone File Groups Image: Comparison of Comparison o	Modeling	Analysis	Drawings	Interop.
		Ana	lysis	
		LEAP Bridge Steel	File Not Created Run application to	o begin.
		LEAP Bridge Concrete	File Not Created Run application to	o begin.

- Click on the Analysis icon.
- Launch LEAP Bridge Concrete.
- Click Open and navigate to the existing lbcx file.

-								
T LEA	P Bridge Concrete CONNECT Ed	ition - Untitled					×	
File Ec	lit View Tools 2D Viewer	Options Help			~			
New (실 📕 🔳 🤞 Open Save Save As Print	A B C Preferences	Graphics Reports Hel) 🛷 🕍 🎽 o Bentley Site About E-r	🤌 mail Send to FTP Tu	vtorials Ben	tley Cloud S	
1	🔂 Open File							×
Pro	← → ~ ↑ <mark> </mark> « (W)D	DataStor (\\ntdfs) (W:)	> Highway > Bridge >	Automation > OBD Testi	ng v	Q O	Search OBD Testin	ng
0	Organize 🔻 New folder						-	•
	OneDrive	Name	~	Date modified	Туре	Size		
Desig	🛄 This PC	CCS.lbcx		1/2/2020 6:40 AM	LBCX File	9,401 KB		
	3D Objects							
	Desktop							
	Documents							
l r	🖶 Downloads							
	👌 Music							
	E Pictures							
Ele	🚪 Videos							
Colun Lop	🏪 Windows (C:)							
Τcμ	🛖 ajeffer (\\ntdfs\F							
- C	🛫 u (\\dot.int.lan\a							
280	🛫 (W)DataStor (\\r							
	🛫 c\$ (\\hlt20272) (.							
	🛫 c\$ (\\hlt23113) (
	🛫 c\$ (\\hdc22375)							
For Help, p	File nan	ne: CCS.lbcx				~ All L	EAP Bridge Concre	ete files (
		·				C)pen 😽	Cancel

- Click Open button.
- The file will be added to the Standalone group once loaded.
- The workflow when working in ProjectWise has slightly different steps to create the obdx file.
 - Select ProjectWise option after launching OpenBridge Designer

	+	*
Browse	New File	ProjectWise
	Browse	Browse New File

- Log in to ProjectWise
- Select New File.
- Navigate through the Select button to the project directory Bridge subfolder in ProjectWise to create the new file.

Folder				Save
I			Select	Save to disk
Document				Cancel
Name:	New File.obd			
Description:				
File Name:	New File.obd			
Format:			Format	
A		Decederati		

Select		
Folders		
	CONNECT PilotProject_01 Concept Concept Construction Co	~
pw:\\n	tPwInt1.dot.int.lan:PWMain\Documents\Projects\z0	•
	OK Ca	ncel

- Click OK button
- Enter a name that matches the project directory number.
- Click Save button.
- Steps 3 11 are the same with the files saved to the ProjectWise location.
 When exiting OpenBridge Designer a Check In dialog box for ProjectWise will display.

neral Comment			
Name		Application	Description
<			>
Folder: Proje	ects\zCONNECT_PilotProject_01	\Bridge	
Folder: Proje	ects\zCONNECT_PilotProject_01 ion during Check In	\Bridge	
Folder: Proje	ects\zCONNECT_PilotProject_01	\Bridge	

• Click Check In button.