

June 17, 2025

Leica Captivate NTRIP Settings

This document provides step-by-step instructions for configuring Leica Captivate NTRIP settings. If you have any questions, please contact your software support.

Dan Messerich, PLS Iowa Real Time Network Administrator

1. From the home screen click on the internet port connection icon in the upper right corner, then click the 'Server / mountpt' button





2. Click the 'Server to use' to change or confirm the NTRIP settings and Source to select the mountpoint.





3. Confirm the NTRIP settings

😔 LeicaCaptivate						
つ Edit Server						
General NTRIP						
Server name	IARTN					
Address	165.206.203.10					
Port	10000					
Store	Page					
	4059000000					
S Edit Server	₩ @ ¹ 2D 1D					
General NTRIP						
Use NTRIP with this server	\checkmark					
NTRIP user ID	NTRIP USER					
NTRIP password	•••••					
Display password						



4. To select the mountpoint from the Home Screen > Settings > Connections > Other Connections > All Other Connections





5. Select Control > Source > Select the mountpoint

😔 LeicaCaptivate								
つ Connect	ion Setting	5	7	×, 0	@	2D 1D	(09:54
CS connections	GS connectio	ons						Q,
RTK rover	Port	GS Intern	et 1					
GS internet Device Cinterion P	LS8 Port	GS moder	m					
NMEA 1 Device -	Port	-						
NMEA 2 Device -	Port	-						
Remote (OW Device -	I) Port	-						
Fn OK		Edit	Con	trol			Page	e Fn
LeicaCaptivate								
Internet	Port Conne	ction		×, 0	@	2D 1D	(09:58
Internet port			GS Int	erne	t 1			
Server to use			IART	N				>
NTRIP mountp	point		MSM	_IMA	٩X			
		mount	points					
ОК					So	ource		
LeicaCaptivate								
	ource Table	ļ		×. 0	@	2D 1D	@	17:04
RTCM3_MAX Identifier RTCM3_I	MAX							
RTCM3_IMA	X MAX							
RTCM3_NEA	R NEAR							
CMRP_NEAR Identifier CMRP_N	EAR							
CMRP_IMAX Identifier CMRP_IM	AX							
MSM_IMAX	IAX							
Fn OK		Info						Fn



6. From the Home Screen Click the Data Link icon and Start RTK stream

