



If manhole depth exceeds 20 feet, install steps.
 Install infiltration barrier.

- ① For new pipe connections, provide cored opening with flexible pipe connector.
- ② For existing pipe connections, provide an arched opening with a diameter up to 6 inches larger than outside diameter of pipe. Install waterstop around existing pipe. Fill void between pipe and opening with non-shrink grout.
- ③ For additional configurations, maintain a minimum of 12 inches of concrete between vertical edges of pipe openings.
- ④ 12 inch minimum riser height above all pipe openings.

Manhole Diameter (inches)	Maximum Pipe Diameter (inches) for 2 Pipes	
	At 180° Separation	At 90° Separation
48	24	18
60	36	24
72	42	30
84	48	36
96	60	42

FIGURE 6010.303 SHEET 1 OF 1

TYPICAL SECTION

SUDAS IOWADOT	REVISION 4 04-20-21
	SW-303 SHEET 1 of 1
FIGURE 6010.303 STANDARD ROAD PLAN	REVISIONS: Added manhole depth note
<i>Paul D. Wigand</i> SUDAS DIRECTOR	<i>Stuart Nade</i> DESIGN METHODS ENGINEER
SANITARY SEWER MANHOLE OVER EXISTING SEWER	