

All Tangled Up:

lowa Department of Transportation

How to Extricate a Vehicle from a High-Tension Cable Median Barrier



Brifen USA Inc

High-tension cable median barrier systems are saving lives

High-tension cable barrier systems are a fairly new safety feature being added to select stretches of lowa highways where there is a higher occurance of median crossover crashes. The barriers are designed to reduce median crossover crashes by keeping errant vehicles on their own side of the road.

When vehicles have become entangled in the cables, emergency service providers have asked: What do we do if there are life-threatening injuries and we can't get to the victims because of the cables. Can the cables be safely cut to save lives?

The answer is "yes," but cutting the cables should be a last resort. There are other options for extrication that allow the cables to remain intact and continue to save other lives. When high-tension cable barriers are cut, thousands of feet of barrier could be placed out of service until repairs can be made.

Barrier system elements

High-tension cable barrier systems used in lowa have either three or four cables. Each cable is held in constant tension in the range

or four cables. Each cable is held

of 3,000 to 8,000 pounds, depending on ambient temperature and seasonal changes.

Although several different hightension cable barrier types exist, they all use the same cable that consists of ¾-inch-diameter galvanized steel cable with 3x7 (21 wires) construction.

Depending on the type of system, the cables may be attached to the weak steel posts using special locking hook bolts or threaded through the posts. The barrier is installed using concrete footings in which metal tubes are cast to form sockets for the posts. After impact, any damaged posts can be removed from the sockets and replaced with new posts.

Turnbuckles are used to achieve the appropriate tension in the system. Turnbuckles are generally installed every 1,000 feet or at lesser distances (as little as 200 feet), if required.

Keep the cables intact and release tension

If a vehicle becomes entangled in the cable, the first instinct of emergency responders is to cut the cable to gain better access to the victims. However, there are better options and cutting the cables should be a last resort using extreme caution and proper procedures. The alternatives to cutting the cable are listed here in order of preference.

Option 1: If satisfactory extrication time exists, lowa DOT maintenance personnel are trained to safely add slack to cable by taking out posts and loosening turnbuckles. To seek lowa DOT assistance during an emergency, contact the lowa DOT's Operations Support Center at 515-233-7900 any time of the day.

Option 2: Move the cables back to their original positions by releasing the tension of the cables. This can be accomplished by driving, pushing or pulling the vehicle back in the opposite manner that it entered the cable system.

Option 3: Lift the cables out of and/or off the posts for approximately 100 feet upstream and downstream of the vehicle. A span of approximately 100 feet without any posts will allow the cables to lie on the ground.


Option 4: Remove the posts from their sockets for approximately 100 feet upstream and downstream of the vehicle. If the cables are under extreme tension, use extra caution and secure the post with a chain or restraining device during removal.



Brifen USA Inc.

Option 5: Tension in the cables can also be released at the nearest upstream and downstream turnbuckles or at one of the cable end anchors, whichever is closest. Use hand tools to loosen the turnbuckle until the end of each threaded terminal reaches the inspection hole. Warning: The threaded terminals should always remain visible in the inspection holes. Unscrewing the turnbuckle or cable anchor end beyond this point can be unsafe. The cables could release rapidly as the threads strip out of the connection.

Option 6: The final option, which is still preferred to cutting the cable, is cutting the turnbuckle. It is much easier and less costly



to replace a turnbuckle than it is to install a cable splice or to replace a section of cable. Before

cutting a turnbuckle, remove the adjacent posts in the vicinity of the turnbuckle, if possible. Loosen the turnbuckle until the end of each threaded terminal reaches the inspection hole. Always cut in the middle of the turnbuckle. Cut only the minimum number of turnbuckles necessary. Safety warning: Although the cable should move only a short distance in each direction after the turnbuckle is cut, everyone except the person making the cut should stand a safe distance clear of the cable. High-tension cables are under thousands of pounds of tension, and a vehicle trapped in the system creates even higher tension forces. Therefore, cutting a turnbuckle has the potential to cause injury.

Cut the cables as a last resort

Although it can be done, cutting cables under tension should be done with caution and only as a last resort where a life-threatening situation exists, time is critical and other alternatives for loosening the cables are not feasible. Cutting cables will require a cable splice or complete cable section replacement, which is time consuming and costly. It also disables a section of the system.

If it is necessary to cut the cable, cut only the minimum number of cables necessary. Make the cut midway between two undamaged posts where the cables are parallel and not being subjected to multiple forces, located several hundred feet from the vehicle.

The cable should be securely taped with duct tape on each side near where the cable will be cut to prevent unraveling. Make the cut standing perpendicular to the system, arms in front. Use either an abrasive blade cutoff saw or hydraulic cutters. Use gloves and safety goggles, and cut very carefully. Pay particular attention when there are only a few strands remaining during the final stage of cutting.

Safety warning: Although the cable should move only a short distance in each direction, everyone except the person making the cut should stand a safe distance clear of the cable. High-tension cables are under thousands of pounds of tension, and a vehicle trapped in the system creates even higher tension forces. Therefore, cutting a cable has the potential to cause injury.

Need crash scene extrication assistance?

lowa DOT maintenance personnel can provide guidance and on-site help at a crash scene 24 hours a day, seven days a week. During an emergency, contact the lowa DOT's Operations Support Center at 515-233-7900 or lowa State Patrol through their dispatch center.

Emergency responders may also call this number to report a damaged or cut cable system following a crash.

More information about high-tension cable barriers

For additional details, visit: www.iowadot.gov/mediancable. htm; or view several cable-cutting demonstration videos using different cutting tools at:

http://www.minnesotafireservice.com/node/491

To learn more about the location and safety benefits of high-tension cable barriers in Iowa, contact the Iowa DOT's Office of Traffic and Safety at 515-239-1557. To learn about the design of these barriers, contact the Office of Design at 515-239-1783.

Federal and state laws prohibit employment and/or public accommodation discrimination on the basis of age, color, creed, disability, gender identity, national origin, pregnancy, race, religion, sex, sexual orientation or veteran's status. If you believe you have been discriminated against, please contact the lowa Civil Rights Commission at 800-457-4416 or lowa Department of Transportation's affirmative action officer. If you need accommodations because of a disability to access the lowa Department of Transportation's services, contact the agency's affirmative action officer at 800-262-0003.

